



# Quick Start Guide

When Playing Music  X1: Play or pause audio being played.


When call incoming  X1: Pick up or hang up


 Start seeking Stereo Pair or Exit Stereo Mode




 X1 Tonggle among Three Modes



 Turns Corbett I Mini ON/OFF  
Corbett I Mini turns itself off  
after 20min inactive.

 X1 Decrease or Increase Volume

 Skip to Previous or Next Song