

# Quick Start Guide



Press and Hold, Power ON/OFF



Toggle among Bluetooth/AUX/microSD Mode  
Press and Hold, Seeking Stereo Pair



Volume Control



Skip to Previous or Next Song



Play/Pause, or  
Pick up / Hang up Phone Call  
Press and Hold, Exit out of Stereo Pairing



Bluetooth Mode



microSD card Mode



USB Audio Decode Mode



AUX Audio Decode Mode



Bluetooth in Stereo Pairing Mode



microSD in Stereo Pairing Mode